

Re: SP III Disatnce Calculation – Operational Question?

Source: <http://sci.tech–archive.net/Archive/sci.geo.satellite–nav/2005–12/msg00788.html>

- *From:* "peter" <prathman@xxxxxxxxxxx>
 - *Date:* 28 Dec 2005 19:40:45 –0800
-

shark572@xxxxxxxxxxx wrote:

> Peter,
> I can turn the receiver off by selecting "Use Indoors" but I can't find
> a "Demo" mode on either of the two menu screens? Can you tell me how to
> get the unit into the Demo mode?

"Use Indoors" is the same thing. As long as it doesn't have a valid position lock it'll let you enter any point as the current location and let you route from there.

.

- *Follow–Ups:*
 - ◆ **[Re: SP III Disatnce Calculation – Operational Question?](#)**
◇ *From:* shark572
- *References:*
 - ◆ **[SP III Disatnce Calculation – Operational Question?](#)**
◇ *From:* shark572
 - ◆ **[Re: SP III Disatnce Calculation – Operational Question?](#)**
◇ *From:* peter
 - ◆ **[Re: SP III Disatnce Calculation – Operational Question?](#)**
◇ *From:* shark572
- Prev by Date: **[Re: Galileo purported 1 m \[horizontal?\] position accuracy](#)**
- Next by Date: **[Re: SP III Disatnce Calculation – Operational Question?](#)**
- Previous by thread: **[Re: SP III Disatnce Calculation – Operational Question?](#)**
- Next by thread: **[Re: SP III Disatnce Calculation – Operational Question?](#)**
- Index(es):
 - ◆ **[Date](#)**
 - ◆ **[Thread](#)**