

Re: Connector Labeling

Source: <http://sci.tech-archive.net/Archive/sci.electronics.cad/2006-08/msg00059.html>

- *From:* Peter Bennett <peterbb@xxxxxxxxxxxxxxxx>
 - *Date:* Mon, 31 Jul 2006 10:02:01 -0700
-

On Mon, 31 Jul 2006 08:04:05 -0400, "Tod Adamson"
<tadamson127@xxxxxxxxxxxx> wrote:

When labeling a connector with a site name when do you use "P" as in P1 or "J" as in J1. I have also seen "E" used. If anyone could explain these labels, I would be greatly appreciative.

I usually use "J" for a panel-mounted connector of either sex, but sometimes will use "P" for a male connector and "J" for female.

—

Peter Bennett VE7CEI

email: [peterbb4 \(at\) interchange.ubc.ca](mailto:peterbb4@interchange.ubc.ca)

GPS and NMEA info and programs: <http://vancouver-webpages.com/peter/index.html>

Newsgroup new user info: <http://vancouver-webpages.com/nnq>

.