

Re: ledit and pspice

Source: <http://sci.tech-archive.net/Archive/sci.electronics.design/2004-10/5125.html>

From: Jim Thompson (*thegreatone_at_example.com*)

Date: 10/18/04

Date: Mon, 18 Oct 2004 07:32:43 -0700

On Mon, 18 Oct 2004 00:29:18 -0400, "~~ VerilogMan ~~"
<zoroux7@rogers.com> wrote:

>Nice , it got better :)
>I get some "Model NMOS used by M1 is undefined" error
>
>
>
>
[snip]

You need a .MODEL statement defining the MOSFET.

Placing "0" for "?" for the "bulk" terminal works on this case since
it's Nmos. But be cautious with an extractor that can't find
"bulk"... add PMOS and the "bulk" can usually be arbitrarily
connected.

...Jim Thompson

```
--  
| James E.Thompson, P.E.           | mens |  
| Analog Innovations, Inc.         | et   |  
| Analog/Mixed-Signal ASIC's and  | manus|  
| Phoenix, Arizona                 |      | Voice:(480)460-2350  
| E-mail Address at Website        |      | Fax:(480)460-2142  
| http://www.analog-innovations.com |      | Brass Rat  
|                                  |      | 1962
```

I love to cook with wine. Sometimes I even put it in the food.