

S-parameter test sets

Source: <http://sci.tech-archive.net/Archive/sci.electronics.design/2005-06/msg02931.html>

- *From:* Terry Given <my_name@xxxxxxx>
 - *Date:* Wed, 22 Jun 2005 16:57:46 +1200
-

what is the most common impedance used with S-parameter test sets - 50 or 75 Ohms? my guess would be 50 Ohms, based on no knowledge whatsoever.

what would be the pros and cons of one vs the other?

I am looking at buying one for my 200MHz HP3577 network analyser

Cheers
Terry

.