

Re: Grundig VCR non-functional

Source: <http://sci.tech-archive.net/Archive/sci.electronics.repair/2004-06/2383.html>

From: Arthur Rinkel (arthur_at_unimatrix001.student.utwente.nl)

Date: 06/29/04

Date: 29 Jun 2004 13:59:31 GMT

Gerald Spindler <nospam.aon.912669373@aon.at> wrote:

Hi,

> *(PSU pulses). Check C1045 (47uF/10V) on PSU sub panel*
I couldn't find that capacitor...

> *and if you mean the relay by "plastic coil" then it is C420 = 100 uF 25V in*
> *supply unit.*

I've replaced the cap. and it fixed the recorder ;-). I.e., electrically it's working, but now the child-lock is in place. According to Google this can be unlocked with a universal code.

I'm curious though, what is the function of C420 in the PSU?

Anyway, many thanks for your help.

Grtz, Arthur