

Tilted picture tube? Panasion 20" flat screen CT-20SXIOC8

Source: <http://sci.tech-archive.net/Archive/sci.electronics.repair/2004-06/2416.html>

From: NAP (*war_with_in_a_breath_at_yahoo.ca*)

Date: 06/30/04

Date: 29 Jun 2004 20:22:11 -0700

I came by this group by an site that offered the service man codes, and was curious if anyone can help me please with this problem that just happend in the last three hours. I had to pick up the TV and move it.

So with out really thinkning, I used those little plastic inserts that look like handles on the back of the TV. When I did this, I picked it up and walked a few feet, and the case kinda popped out but didn't(no screws are broken or anything, not actualy damage). Can't really explain what happend. I just know it moved some how. Anyways, when I hooked everything back up, I decided to play an video game, and turned on my gamecube. This is where I notice that the picture became some how tilted. Not by much, but judging by the screen postion move option in my cubes boot up screen. The picture gone up to the left by about 1-3 inches maybe, giving me an slight tilt or slope down to hte right. Everything visiable, but it quite noticable whenever anything widescreen is played on the TV. And some what annoying.

I'm curios if I can go about fixing this. I figure I have to open up the TV as it where. But if I do, what do I need to do? Or did I do something that beyond any joe smo, and perhapes bring it into an repair shop. Thx in advantce for any and all info. (I included the model number incase it needed)