

## Re: Pinout for pro video VCR camera connector JVC CR-4900U U-matic

**Source:** <http://sci.tech-archive.net/Archive/sci.electronics.repair/2004-06/2423.html>

---

**From:** Wild Bill (*kwag98\_at\_usachoice.net*)

**Date:** 06/30/04

Date: Wed, 30 Jun 2004 03:11:01 -0400

Thanks for your help. The first link (rcrowley) had the specific pinout I was looking for.. Sony DXC-3000 camera connectors.

The second link (geocities) shows a different type of 14-pin consisting of 3 rows of four pins and 1 row of two pins.

The other 10-pin connector shown on the same page is the fairly common consumer camera 10-pin connector used on Quasar, RCA, Panasonic camera cables when cameras were cabled to portable VHS VCRs.

Cheers

WB

.....

"gothika" <Vampyres@nettaxi.com> wrote in message  
news:7pb3e05nfp8kaa15a5il0e3o704gjp112h@4ax.com...

> *It's commonly referred as the Sony 14pin connector.*

>

> *Here are a few links:*

>

> <http://www.rcrowley.com/SonyPinout.htm>

>

> <http://www.geocities.com/vk3rtv/camcon.html>

>

>