

## Samsung DVD P-231 player

**Source:** <http://sci.tech-archive.net/Archive/sci.electronics.repair/2004-07/0526.html>

---

**From:** Viatcheslav Riabov ([vriabov\\_at\\_eudoramail.com](mailto:vriabov_at_eudoramail.com))

**Date:** 07/06/04

Date: 6 Jul 2004 06:35:26 -0700

Good day, gentlemen (and ladies).

My own DVD player Samsung DVD P-231 went belly up.

It still plays nicely regular music CDs, but fails on DVD and MP3 disks with "No disk" error.

Of course, I cleaned the reader, to no avail.

I have read all postings and even out of my own experience,

I see that it may be not economically worth of repairing it.

Anyway, do I have any hope for an optimism? The fact that it plays regular CDs is confusing – maybe it is still possible to do something about it.

Regards,

Viatcheslav Riabov