

Re: Sony Trinitron goes off and on, off and on

Source: <http://sci.tech-archive.net/Archive/sci.electronics.repair/2004-08/2255.html>

From: davexnet02 (davexnetzerotwo_at_hooya!.com)

Date: 08/27/04

Date: Fri, 27 Aug 2004 00:32:28 GMT

On Thu, 26 Aug 2004 06:11:19 GMT, "Jim Beaver"

<jumblejim@prodigy.spam> wrote:

>I've got a bulky Sony Trinitron XBR exhibiting weird symptoms. First I
>noticed that it was taking an inordinately longer time to come on when
>turned on. It takes anywhere from thirty seconds to two minutes to get the
>degaussing click and for the red light to start flashing on the front of the
>cabinet. Once those two things happen, it warms up and pictures up within
>the normal time frame.
>
>Then, after a few days of this, it began turning itself off and eventually
>back on, usually at but not restricted to times when my air conditioning
>system cycled on. There is a dark translucent strip at the top front of
>the cabinet, above the screen, that lights up a dim red after the set has
>turned itself off. This dim red glow continues for however long it takes
>the set to get back to being ready to come on again. Then the red glow goes
>out, the set clicks, the red light starts flashing, then the set comes back
>on as though nothing had happened. Ten minutes or five minutes or half an
>hour later, it does it again. Like I say, it's usually when the air
>conditioner comes on, but not always.
>
>A minor and unrelated problem: I can't find my remote for this set, and
>can't figure out how to get rid of the word 'LINE' displayed on the screen
>in the lower right. It's been there for weeks. I know there's probably a
>menu or display button on the remote, but how can I get rid of it without
>the remote?
>
>Sorry I haven't got exact model numbers. It's a huge set, too big for me to
>manhandle by myself, and it's in place in a TV armoire and I can't readily
>access the back.
>
>Thanks.
>
>Jim Beaver
>

This is remarkable, I'm having almost identical problems with my
27 inch XBR (from 1992). That strip at the top lights up when the
set is plugged in, stays lit for about 2 minutes, goes out by itself,

sci.electronics.repair: Re: Sony Trinitron goes off and on, off and on

and the TV immediately turns on.

That strip with the small red lights is the headphone transmitter.

On my set, if I hit the headphones button on the RC, the set turns off immediately.

How/Why such a thing should be involved seems odd to me, but there you go. I'm just amazed that two people suffered this same weird thing at the same time...

I've already started researching repair shops in my area.

Dave