

## Re: update: Panasonic VCR PV-V4022 keeps shutting down in play or FFWD

**Source:** <http://sci.tech-archive.net/Archive/sci.electronics.repair/2005-03/0233.html>

---

**From:** Phil Bowser (*pbowser\_at\_pa.net*)

**Date:** 03/03/05

Date: Thu, 03 Mar 2005 02:27:13 GMT

I'd say you just proved that the sensor IS bad indeed (You moved the problem to the supply reel, where it causes the rewind to quit working, just as you said...) In playback and other forward modes (Search, FF) both sensors are monitored, and unit will shut down if pulses are not received, or are too low in amplitude (bad sensor). Panasonic has an excellent website where they will sell consumers any part they want. Use the "search parts by model" feature...

<worley45@aol.com> wrote in message news:42229B7E.F08C0F8F@aol.com...

- > *OK I tried replacing the take-up reel sensor with the sensor from the*
- > *supply reel, but it still doesn't work ( just made the rewind quit*
- > *working ). Do both sensors have to be good for the play & FFWD to work?*
- > *Also, where is a good place to buy these?*
- >
- > *dkuhajda@locl.net wrote:*
- >
- > *> Take up reel sensor.*
- >