

Re: Panasonic Detritus

Source: <http://sci.tech-archive.net/Archive/sci.electronics.repair/2005-03/0799.html>

From: Art (plotsligt_at_comcast.net)

Date: 03/12/05

Date: Sat, 12 Mar 2005 06:56:20 -0500

Removal of debris from the Pickup in a CD or DVD device: Use of canned air (Compressed Air in a pressurized container) is preferred. Open the drawer of the device, direct the air via the supplied plastic nozzle, and just blow the debris out of the device. Severe cases of sticky debris can be removed with a "Q-Tip" and rubbing alcohol, with extremely light pressure being exerted against the actual pickup.<

> *However the preferred method is the air "blow off". If indeed you are
> accumulating a large amount of debris in a very short period of time it
> may be a good idea to evaluate the environmental conditions of use of your
> product.*

"Heinreich Heiligestrassen" <HHeiligestrassen@twdallas.rr.com> wrote in message news:0BuYd.2272\$U_4.330@fe2.texas.rr.com...

> *My Panasonic DVD player keeps getting detritus on the laser pickup. How do
> I clean this material off?*