

Re: Panasonic Detritus

Source: <http://sci.tech-archive.net/Archive/sci.electronics.repair/2005-03/0812.html>

From: Shoreline Electronics (jstielau_at_snet.net)

Date: 03/12/05

Date: Sat, 12 Mar 2005 14:32:22 GMT

Detritus is debris...ashes...crumbs...remains. It's what's left after something has been used up.

We may need to look at the root of the causedirty/dusty accommodations perhaps?

Buy a lens cleaning disc to accomplish what you asked.

=====
Jeff Stielau
Shoreline Electronics Repair
344 East Main Street
Clinton,CT 06413
860-399-1861
860-664-3535 (fax)
jstielau@snet.net
=====

"Heinreich Heiligestrassen" <HHeiligestrassen@twdallas.rr.com> wrote in message [news:0BuYd.2272\\$U_4.330@fe2.texas.rr.com](mailto:news:0BuYd.2272$U_4.330@fe2.texas.rr.com)...

> *My Panasonic DVD player keeps getting detritus on the laser pickup. How do*
> *I clean this material off?*