

Coby DVD-224 Progressive scan dvd/cd/mp3 player No power problem Fixed

Source: <http://sci.tech-archive.net/Archive/sci.electronics.repair/2005-06/msg00246.html>

- *From:* Bill Degener <bill@xx>
 - *Date:* Sat, 04 Jun 2005 12:13:46 -0500
-

No power light, ticking noise at transformer. Jumper J2 (cold solder joint), replaced capacitor C11 rated at 10v but was on 12v circuit hmmm(high esr), and capacitor C9 on 5v circuit (high esr). Works :-)

.