

Toshiba 21S04BG Colour TV Service Mode?

Source: <http://sci.tech-archive.net/Archive/sci.electronics.repair/2005-10/msg00841.html>

- *From:* "MCP" <gf010w5035@xxxxxxxxxxxxxxxxxxxx>
 - *Date:* Thu, 13 Oct 2005 10:26:02 GMT
-

Hi All, Can anyone please tell me if this set has a service mode and how to get into it?

I can access the menu ok to change to sound and that by just pressing the menu button on the remote but can not get the S to appear on screen, help!!

George