

Re: Toshiba 21S04BG Colour TV Service Mode?

Source: <http://sci.tech-archive.net/Archive/sci.electronics.repair/2005-10/msg00917.html>

- *From:* "MCP" <gf010w5035@xxxxxxxxxxxxxxxxxxxx>
 - *Date:* Fri, 14 Oct 2005 10:47:19 GMT
-

"Skype_man" <skype_man@xxxxxxxxxxxx> wrote in message news:9ZSdnY2cyZje-dLenZ2dnUVZ_s2dnZ2d@xxxxxxxxxxxx...
Put the volume on minimum on the front volume down button, then hold the volume down button, while holding the number 9 on the remote. This will get you in. Be careful not to foul it up, & write down each setting. There are a lot. Sky.

Thank's a lot M8