

# Odd DVD Problem, RCA TV/VCR/DVD 27F500TDV

---

*Source:* <http://sci.tech--archive.net/Archive/sci.electronics.repair/2005-12/msg01522.html>

---

- *From:* [bpetria@xxxxxxxxxxx](mailto:bpetria@xxxxxxxxxxx) (Brad)
  - *Date:* Fri, 23 Dec 2005 17:48:49 GMT
- 

Hi,

I have an RCA TV/VCR/DVD combo, model 27F500TDV (mfg Nov 2003) in my shop. When you try to play a DVD, a message, "Incorrect Disk" occurs. I also tried a home made DVD which has home videos recorded on the disk (same message). Note: I tried 3 other DVDs (same message). However, audio CDs will play just fine. Note: I cleaned the lens, which already looked very clean. Inside, everything is very clean.

If I replaced the DVD player assembly, will this fix the problem?

Thanks in advance, Brad

Before you type your password, credit card number, etc., be sure there is no active key logger (spyware) in your PC.

.

---

- *Follow-Ups:*
  - ◆ **[Re: Odd DVD Problem, RCA TV/VCR/DVD 27F500TDV](#)**
    - ◇ *From:* Jumpster Jiver
- Prev by Date: **[Re: Tektronix oscilloscope focus pot.](#)**
- Next by Date: **[Re: Cracked Lenticular Screen](#)**
- Previous by thread: **[What is Becker Car-Fi ?](#)**
- Next by thread: **[Re: Odd DVD Problem, RCA TV/VCR/DVD 27F500TDV](#)**
- Index(es):
  - ◆ **[Date](#)**
  - ◆ **[Thread](#)**