

Re: Audio jack identification

Source: <http://sci.tech-archive.net/Archive/sci.electronics.repair/2006-04/msg01487.html>

- *From:* iazz <le_ouaou@xxxxxxxxxx>
 - *Date:* Mon, 24 Apr 2006 21:26:42 +0200
-

On Mon, 24 Apr 2006 19:06:16 +0000, Travis Jordan wrote:

iazz wrote:

Hi,

The audio jack in my laptop (a sony vaio z1) died and I would like to replace it. I checked the digikey catalog but could not determine whether they have a compatible model.

What makes you think the problem is the jack? Did it physically break?

Ah, yes, I suppose so.

When I plug headphones, the main speakers don't mute anymore and in the headphones I can hear what sounds very much like the difference between the two channels in mono (probably the jack now connects one channel to both outs and the other to the ground). When the phones are unplugged, the sound coming out of the main speakers is okay.

The little blades inside must be broken.

.