

Sony WEGA TV problem

Source: <http://sci.tech-archive.net/Archive/sci.electronics.repair/2006-09/msg00270.html>

- *From:* "swarfmaker" <iain@xxxxxxxxxxxxxxxxxxxx>
 - *Date:* Mon, 4 Sep 2006 19:05:08 +0100
-

I can't get rid of the on-screen AV channel indicator (top left of screen). I've tried the button with the cross inside a square, but this only cycles through the screen size options (widescreen, 4:3, etc). I've tried the button with the right-pointing arrow into a square, but this cycles through some other screen options. The set is only used on AV mode as I only have Sky.
Anyone got ideas as to how to get rid of this indicator.
TIA
Iain