

Xerox 1025 copier Problem

Source: <http://sci.tech--archive.net/Archive/sci.electronics.repair/2006-11/msg00035.html>

- *From:* Joe <a0010631@xxxxxxxxxxxx>
 - *Date:* Tue, 31 Oct 2006 17:58:20 -0600
-

Does anyone know what status code U4 signify? I turn the machine on, it says "wait" while warming up and then shuts down with status code U4.

It has been working fine up until today. It would go into status code U4 whenever there was a delay in copying something. Is it a "sleep" function? I would turn off the machine and turn it on again and it would work just fine until today.

Thanks in advance

Joe

.