

# Phillips DCC900

---

*Source:* <http://sci.tech-archive.net/Archive/sci.electronics.repair/2006-11/msg01257.html>

---

- *From:* Wilfred <[wilfred@xxxxxxxxxxxxxxxxxxxxxxxx](mailto:wilfred@xxxxxxxxxxxxxxxxxxxxxxxx)>
  - *Date:* Tue, 21 Nov 2006 00:55:13 GMT
- 

I have a DCC900 digital cassette deck. It plays analogue tapes fine but suddenly stopped reading digital tapes cleanly. I don't think it is a serious fault because it will occasionally sense a tape and play a bit but it suffers dropouts.

It played well when it was put away. I dragged it out just to play with it a bit (gone retro :-). So the time sitting idle 6-7 years seems to be a factor perhaps.

Does anyone know the likely cause of this. Or even a list of common faults?

Are there service docs available on the 'net?

Regards Wilfred

.