

HP LaserJet 4050N

Source: <http://sci.tech-archive.net/Archive/sci.electronics.repair/2007-01/msg00833.html>

- *From:* "Alasdair Campbell" <ragawu@xxxxxxxxxx>
 - *Date:* Sun, 14 Jan 2007 02:12:09 -0000
-

LaserJet 4050N with blank line lengthways down middle of each print, about 5mm wide. Only appeared after being unused for 3 months.

Service manual says I need to start replacing huge parts of the printer, but I was hoping for other ideas.

I've dismantled it as far as I can and can't see any alien objects, or signs of wear.

Haven't started looking at main printing stage, as I wouldn't know where to start. Are there manuals that doc dismantling this sort of thing?

.