

Help With My Zenith Console TV SZ2549P

Source: <http://sci.tech--archive.net/Archive/sci.electronics.repair/2007-03/msg00799.html>

- *From:* nick@xxxxxxxxxxxxx
 - *Date:* 15 Mar 2007 17:00:18 -0700
-

Hello I appreciate anyones help they can give. I have a Zenith TV model number SZ2549P It was made in 1984 and its a console TV. Before you ask "Why is he trying to repair this" let me explain. This TV was my granfathers. It hasnt worked since I was 5 years old. This was state of the art in its day it has something called "Space Phone" basically its a speaker phone inside the TV. Anyway he lost his fight to cancer back in 2002. It was always somthing we were going to do together was to fix this but he past prior to us doing it. He left me this TV thinking it would have been fixed by the both of us, and his old Console Zenith Stereo (Works Great). I want to fix this TV in his memory and use it in my living room, I know he would be proud.

This is what is happening. When I plug the unit in and press the power button eaither on the remote or the front panel I hear a click but there is no action its dead other than that click. Through my granpops teachings I am a do it yourselfer. So I did alot of research and I found The Main Module board part number 9-214 and replaced it, and I also found part number 9-186-06 Which is the HI Module and replaced it however I still get the same symptom. The only two boards left are the tuner Module and the Space phone module. I dont think its these. When I did replace the Hi Voltage module I noticed that there is a small board with a power supply (SMall) mounted to it this I couldnt really find a part number on but could this be it? Any help would be so greatly appreciated! Thsi is more than a TV to me.

Thanks

Nick

.