

# Wireless Speakers: RCA Speakers Only Work when on Same Electrical Outlet as Transmitter / What is Problem?

---

*Source:* <http://sci.tech-archive.net/Archive/sci.electronics.repair/2007-04/msg00974.html>

---

- *From:* Lin <[llander@xxxxxxxx](mailto:llander@xxxxxxxx)>
  - *Date:* 19 Apr 2007 10:57:27 -0700
- 

I have wireless speakers (RCA Model RC-070 with Power Line Transmitter) that ONLY work when the POWER CORD FOR THE SPEAKERS is plugged into the SAME electrical outlet as the POWER CORD FOR THE TRANSMITTER.

If the speakers are plugged into an outlet that is different from the outlet for the transmitter, the speakers do not work. If I plug the speakers into a power strip that is on the same outlet as the transmitter, the speakers work. I have tried a variety of electrical outlets (same outlets for both and different outlets for each) and I get the same result. I have concluded that, for some reason, the speakers and transmitter must be plugged into the same electrical source(outlet). This problem defeats the purpose of the wireless speakers that I want to put in a different room from the transmitter.

Does anyone have any suggestions as to the problem and how I can correct it?

Thanks.

.