

# Sharp JX9660 laser printer odd fault (dead, sort of)

---

*Source:* <http://sci.tech-archive.net/Archive/sci.electronics.repair/2007-11/msg01243.html>

---

- *From:* "Martin Whybrow" <[aholeintheground@xxxxxxxxxxxxx](mailto:aholeintheground@xxxxxxxxxxxxx)>
  - *Date:* Tue, 27 Nov 2007 00:35:54 GMT
- 

I've just reassembled my JX9660 after tearing it down to clean all the rollers in an attempt to fix a recurrent paper jam. On powering it up, the lights flash briefly but the display stays blank, the transport motor starts and the polygon runs up; after a few seconds the polygon stops and just the fan remains on cycling 1 minute on and 5 minutes off (as if it's in power save mode). I have been able to run the diagnostics mode, check the switches, the high voltage section and run a test print although it still jams frequently but it still won't power up normally. I reset the NVRAM and then reset all the counters to the previous values in case there was a problem with corrupt NVRAM but it's still the same. The manual doesn't list this particular condition in the fault symptoms and I'm stumped.

Any ideas or suggestions?

Martin

—

[martin<dot here>whybrow<at here>ntlworld<dot here>com](mailto:martin<dot here>whybrow<at here>ntlworld<dot here>com)

.