

DLP

Source: <http://sci.tech-archive.net/Archive/sci.electronics.repair/2008-04/msg01519.html>

- *From:* zekfrivo@xxxxxxxxxxxxxxxxxxx (GregS)
 - *Date:* Mon, 28 Apr 2008 14:41:29 GMT
-

Working on a DLP projector, no light. I don't measure any voltage going to a lamp socket with lamp disconnected. I looked for both AC and DC. Looks like there is a whole board for the supply with OSRAM parts. Anything else to check ?

greg

.