# Re: floppy drive interface specifications

***Source:*** http://sci.tech−archive.net/Archive/sci.electronics.design/2006−05/msg00070.html

- *From*: pbdelete@xxxxxxxxxxxxxxxxxxxxxxxxxxxxxxxxxxxx
- *Date*: 01 May 2006 14:19:36 GMT

Rene Tschaggelar <none@xxxxxxxx> wrote:

> I tried the manufacturers and wasn't able to
> find them there. The floppy drive interface
> specifications. To connect a floppy to an embedded
> system, I should have the pin descriptions, their
> function and timing. How and what commands are sent.

Here you have some in−depth specifications:
www.teac.de/dspd/downloads/datasheets/dl_fd05hf8630.pdf

5.25" and 3.5" doesn't differ interface wise.

Here's the pinout:
http://www.hardwarebook.net/connector/storage/internaldisk.html

Pay attention to these signals:
Select drive
Head select
Enable motor
Step direction
Step signal
Read data
Track−0

What is the objective .. ?

.